

Accounting for gravity when using a deadweight tester or piston gauge

To establish pressures using a deadweight tester (DWT) or piston gauge, the user must account for the acceleration of gravity at the location where the instrument is operated. It is important to note that the acceleration of gravity varies substantially around the world. With a range of approximately 0.5%, the local gravity correction is typically the largest environmental influence acting on the deadweight tester.



The most accurate method for the user to determine the acceleration of gravity at the laboratory or other site where the deadweight tester will be used is to have a site survey performed. There are various companies that can provide this type of service. Although this is the most accurate method, it can also be expensive.

To determine the acceleration of local gravity value when a survey or site measurement is unavailable, the resources listed below are available on the Internet.

1. Use one of the following options to determine the latitude, longitude, and elevation at the site the deadweight tester will be used:
 - Obtain latitude and longitude coordinates using a GPS receiver, or
 - Use an Internet-based geo-coding program
 - <http://maps.google.com> (use “link” button to show Lat-Lon)
 - <http://www.getlatlon.com>
 - <http://mapper.acme.com>
 - <http://itouchmap.com/latlong.html>
2. Enter latitude and longitude coordinates into one of the following internet-based programs:
 - NOAA/NGS web site (limited to the contiguous 48 United States)
 - http://www.ngs.noaa.gov/cgi-bin/grav_pdx.prl
 - PTB (National Metrology Laboratory of Germany) web site (global)
 - <http://www.ptb.de/cartoweb3/SISproject.php>

For the P3XXX Series Deadweight Testers, customers have two choices. The deadweight tester can be provided matched to standard gravity (9.80665 m/s²) and the customer can utilize software (such as Fluke Calibration PressCal) to account for the acceleration of local gravity. Or, the deadweight tester can be provided matched to the local gravity value supplied by the customer. This is a service Fluke Calibration offers at no additional charge. In the latter case, customers must provide their local gravity on the purchase order.

For piston gauges, such as the 2400 Series and PG7000 Series, the local gravity must be entered into either the terminal (PG7000 series) or software that will be used for the piston gauge calculation (WinPrompt or COMPASS® for Pressure software).

For customers who do not have a site survey, the methods available on the Internet provide a possible resource for determining the gravity at their location. The uncertainties estimated using this method range from about 0.0002 % up to 0.002 %. Customers should use these at their own discretion to determine if the local gravity provided is suitable for the intended use.



Fluke Calibration. Precision, performance, confidence.™

Electrical	RF	Temperature	Pressure	Flow	Software
------------	----	-------------	----------	------	----------

Fluke Calibration
 PO Box 9090,
 Everett, WA 98206 U.S.A.

Fluke Europe B.V.
 PO Box 1186, 5602 BD
 Eindhoven, The Netherlands

For more information call:
 In the U.S.A. (877) 355-3225 or Fax (425) 446-5116
 In Europe/M-East/Africa +31 (0) 40 2675 200 or Fax +31 (0) 40 2675 222
 In Canada (800)-36-FLUKE or Fax (905) 890-6866
 From other countries +1 (425) 446-5500 or Fax +1 (425) 446-5116
 Web access: <http://www.flukecal.com>

©2012, 2014 Fluke Calibration. Specifications subject to change without notice.
 Printed in U.S.A. 2/2014 4218960B_EN
 Pub_ID: 11949-eng

Modification of this document is not permitted without written permission from Fluke Calibration.