

Instrument Security Procedures

Model: Fluke 1529

Product Name: Chub-E4 Standards Thermometer

Instrument Description: Four-channel digital thermometer readout

Memory Description: The product contains non-volatile memory for recording temperature measurements. Temperature measurement data can be easily cleared. Non-volatile memory is also used for storing user settings and calibration correction coefficients. Settings cannot be erased but may be changed.

Memory Clearing Instructions:

To clear stored measurement data, follow these steps:

1. From the Menu, go to LOGGING, DEMAND LOG, DELETE DATA. Select "DELETE: ALL DATA" and push the **Enter** key to delete all demand log data.
2. From the Menu, go to LOGGING, AUTO LOG, DELETE DATA. Select "DELETE: ALL DATA" and push the **Enter** key to delete all auto log data.
3. To verify that measurement data has been erased, go to LOGGING, LOG STATS. FILLED should show 0.0 % and the second number after FREE should show 0.