

# PPC™/ MPC™ Vacuum Kit

P/N 3584473 (110V) - P/N 3584486 (220V)


## Instruction Sheet

*Vacuum Kit includes:*

DESCRIPTION	QTY	PART NO.
Vacuum Pump Assembly	1	
Adaptor 3/8 in. Swage x 1/8 in. NPTM	1	3141557
Adaptor 3/8 in. Swage x 3/8 in. NPTM	1	3480098
Adaptor 3/8 in. Swage x 1/4 in. NPTM	1	3134815
3/8 in. O.D. Tubing (200cm)	1	3232445

*The PPC/MPC Vacuum Kit should be installed as illustrated below. Fill the vacuum pump with oil before using. Read the Fast Vac instruction sheet for additional information.*

*The solenoid valve protects the vacuum pump when turned off. When the operator decreases pressure in a PPC, test gas will be exhausted through the valve. This ensures that the gas will not flow into the pump. The valve is electrically connected to the vacuum pump power switch and actuates automatically.*



**Figure 1: Fast Vac Vacuum Pump Illustrated Parts**