

# Manual Supplement

Manual Title:	9150 Users Guide	Supplement Issue:	<b>3</b>
Part Number:	3729502	Issue Date:	7/19
Print Date:	March 2014	Page Count:	2
Revision/Date:			

---

---

This supplement contains information necessary to ensure the accuracy of the above manual.



## Change #1, 444

On page 1-1, add the following to the **Symbols** table:

	Conforms to relevant South Korean EMC Standards.
---	--

On page 3-1, under **Specifications**, add:

<b>Electromagnetic Compatibility (EMC)</b>	
International	<p>IEC 61326-1: Basic Electromagnetic Environment                  CISPR 11: Group 1, Class A</p> <p><i>Group 1: Equipment has intentionally generated and/or uses conductively-coupled radio frequency energy that is necessary for the internal function of the equipment itself.</i></p> <p><i>Class A: Equipment is suitable for use in all establishments other than domestic and those directly connected to a low-voltage power supply network that supplies buildings used for domestic purposes. There may be potential difficulties in ensuring electromagnetic compatibility in other environments due to conducted and radiated disturbances.</i></p> <p><i>Emissions that exceed the levels required by CISPR 11 can occur when the equipment is connected to a test object.</i></p>
Korea (KCC)	<p>Class A Equipment (Industrial Broadcasting &amp; Communication Equipment)</p> <p><i>Class A: Equipment meets requirements for industrial electromagnetic wave equipment and the seller or user should take notice of it. This equipment is intended for use in business environments and not to be used in homes.</i></p>
USA (FCC)	<p>47 CFR 15 subpart B. This product is considered an exempt device per clause 15.103.</p>

## Change #2, 571

On pages 1-4 and 1-5, replace the **1.3 Authorized Service Centers** with:

### How to Contact Fluke

To contact Fluke, call one of the following telephone numbers:

- Technical Support USA: 1-877-355-3225
- Calibration/Repair USA: 1-877-355-3225
- Canada: 1-800-36-FLUKE (1-800-363-5853)
- Europe: +31-40-2675-200
- Japan: +81-3-6714-3114
- Singapore: +65-6799-5566
- China: +86-400-810-3435
- Brazil: +55-11-3759-7600
- Anywhere in the world: +1-425-446-6110

To see product information or download manuals and the latest manual supplements, visit Fluke Calibration’s website at [www.flukecal.com](http://www.flukecal.com).

To register your product, visit <http://flukecal.com/register-product>.

On page 3-1, under **Specification** add:

**Fuse**..... 115 V: F 12 A, 250 V, 230 V: F 6.3 A, 250 V  
**Remote Interface** ..... RS-232 port  
**Safety** ..... IEC 61010-1; Overvoltage Category II, Pollution Degree 2

## Change #3, 657

On page 1-2, add the following **Warnings**:

### **Warnings**

- **Read all safety information before you use the Product.**
- **Carefully read all instructions.**
- **Do not alter the Product and use only as specified, or the protection supplied by the Product can be compromised**
- **Do not use the Product around explosive gas, vapor, or in damp or wet environments.**
- **Use this Product indoors only.**
- **Use only the mains power cord and connector approved for the voltage and plug configuration in your country and rated for the Product.**
- **Use only the mains power cord and connector approved for the voltage and plug configuration in your country and rated for the Product.**
- **Replace the mains power cord if the insulation is damaged or if the insulation shows signs of wear.**
- **Make sure the ground conductor in the mains power cord is connected to a protective earth ground. Disruption of the protective earth could put voltage on the chassis that could cause death.**
- **Do not use the Product if it operates incorrectly.**
- **Do not use the Product if it is altered or damaged.**
- **Do not put the Product where access to the mains power cord is blocked.**
- **Use caution when you install and remove probes and inserts from the Product. They can be hot.**
- **Use only specified replacement fuses.**
- **Have an approved technician repair the Product.**